

Release Date: 2012-07-10, ver 1.0

WDT For Linux

--This driver supports follwing Linux OS:

Fedora Core  
Ubuntu  
Open SUSE

---

## I. Component

---

The driver is composed of several parts:

1. WDT folder
  - 1.1 User guide
  - 1.2 WDT-EC
    - .\EC
    - .\WDT.txt
  - 1.3 WDT-SIO
    - .\SIO
    - .\WDT.txt

---

## II. Execute

---

You can enter directory of WDT-EC or WDT-SIO to execute follwing application.

1. Execution the application as below

SIO ;For SIO-8772,8728,8731 product only  
EC ;For EC product

2. You can check more informations of command ,

If EC success execution , you will see the wording [FILE OPEN PASS and  
START WDT]

If SIO success execution , you will see the wording [SIO FILE OPEN  
PASS]