

## aileunⅢシリーズ カメラ操作一覧

aileunⅢシリーズ (YS-2500M/YS-2500MC/YS-3000M/YS-3000MC) からカメラ操作を行った場合のカメラ機種ごとの動作です。

ソフトウェア・バージョンは最新である必要があります。

### ●Panasonic (カメラ BB)

|               | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|---------------|--------|-----|-------|--------------|--------------|-------|
| BB-<br>HCM100 | ×      | ×   | ×     | ×            | ×            | ×     |
| BB-<br>HCM110 | ○      | ×   | ×     | ×            | ○            | ○     |
| BB-<br>HCM511 | ○      | ×   | ×     | ×            | △            | △     |
| BB-<br>HCM515 | ○      | ×   | ×     | ×            | △            | △     |
| BB-<br>HCM527 | ○      | ○   | ×     | ×            | ○            | ○     |
| BB-<br>HCM531 | ○      | ×   | ×     | ×            | △            | △     |
| BB-<br>HCM547 | ○      | ○   | ×     | ×            | △            | △     |
| BB-<br>HCM580 | ○      | ○   | ○     | ○            | ○            | ○     |
| BB-<br>HCM581 | ○      | ○   | ○     | ○            | ○            | ○     |
| BB-<br>HCM701 | ×      | ×   | ×     | ×            | ×            | ×     |
| BB-<br>HCM705 | ×      | △   | ×     | ×            | ×            | ×     |
| BB-<br>HCM715 | ○      | △   | ×     | ×            | ○            | ○     |

|           |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|
| BB-HCM735 | ○ | △ | × | × | △ | △ |
| BB-SC364  | ○ | ○ | ○ | ○ | ○ | ○ |
| BB-SC382  | ○ | ○ | ○ | ○ | ○ | ○ |
| BB-SC384  | ○ | ○ | ○ | ○ | ○ | ○ |
| BB-SP104W | × | × | × | × | × | × |
| BB-ST162  | ○ | ○ | × | × | △ | △ |
| BB-ST165  | ○ | ○ | × | × | ○ | ○ |
| BB-SW172  | ○ | ○ | × | × | △ | △ |
| BB-SW174W | ○ | ○ | × | × | △ | △ |
| BB-SW175  | ○ | ○ | × | × | ○ | ○ |
| BB-SW374  | ○ | ○ | ○ | ○ | ○ | ○ |

○：動作します △：動作保証外です ×：動作しません

### ●Panasonic (i-pro)

|               | パン・チルト | ズーム | フォーカス | オートフォーカス | ホームポジション | プリセット |
|---------------|--------|-----|-------|----------|----------|-------|
| DG-NF282      | ×      | ○   | ×     | ×        | ×        | ×     |
| DG-NF302      | ×      | ×   | ×     | ×        | ×        | ×     |
| DG-NP244      | ×      | ○   | ×     | ×        | ×        | ×     |
| DG-NP304      | ×      | ×   | ×     | ×        | ×        | ×     |
| DG-NP502      | ×      | ×   | ×     | ×        | ×        | ×     |
| DG-NS202A     | ○      | ○   | ○     | ○        | ○        | ○     |
| DG-NW502S     | ×      | ×   | ×     | ×        | ×        | ×     |
| DG-NW960      | ○      | ○   | ○     | ○        | △        | △     |
| WJ(DG)-GXE100 | △      | △   | △     | △        | △        | △     |
| WJ(DG)-GXE500 | △      | △   | △     | △        | △        | △     |
| WV(DG)-S1110  | ×      | ×   | ×     | ×        | ×        | ×     |

|                  |   |   |   |   |   |   |
|------------------|---|---|---|---|---|---|
| WV(DG)-<br>S1111 | × | × | × | × | × | × |
| WV(DG)-<br>S1112 | × | × | × | × | × | × |
| WV(DG)-<br>S1130 | × | × | × | × | × | × |
| WV(DG)-<br>S1131 | × | × | × | × | × | × |
| WV(DG)-<br>S1510 | × | × | × | × | × | × |
| WV(DG)-<br>S1511 | × | × | × | × | × | × |
| WV(DG)-<br>S1531 | × | × | × | × | × | × |
| WV(DG)-<br>S2110 | × | × | × | × | × | × |
| WV(DG)-<br>S2111 | × | × | × | × | × | × |
| WV(DG)-<br>S2130 | × | × | × | × | × | × |
| WV(DG)-<br>S2131 | × | × | × | × | × | × |
| WV(DG)-<br>S2511 | × | × | × | × | × | × |
| WV(DG)-<br>S2531 | × | × | × | × | × | × |
| WV(DG)-<br>S6110 | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>S6130 | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>S6111 | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>S6131 | ○ | ○ | ○ | ○ | ○ | ○ |

|                   |   |   |   |   |   |   |
|-------------------|---|---|---|---|---|---|
| WV(DG)-<br>S6530  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SC385  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SC386  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SC387  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SC588  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SF132  | × | × | × | × | × | × |
| WV(DG)-<br>SF135  | × | × | × | × | × | × |
| WV(DG)-<br>SF138  | × | × | × | × | × | × |
| WV(DG)-<br>SF334  | × | × | × | × | × | × |
| WV(DG)-<br>SF335  | × | × | × | × | × | × |
| WV(DG)-<br>SF438  | △ | △ | △ | △ | △ | △ |
| WV(DG)-<br>SF539  | × | × | × | × | × | × |
| WV(DG)-<br>SFN110 | × | × | × | × | × | × |
| WV(DG)-<br>SFN130 | × | × | × | × | × | × |
| WV(DG)-<br>SFN310 | × | × | × | × | × | × |
| WV(DG)-<br>SFN311 | × | × | × | × | × | × |
| WV(DG)-<br>SFN531 | × | × | × | × | × | × |

|                   |   |   |   |   |   |   |
|-------------------|---|---|---|---|---|---|
| WV(DG)-<br>SFN611 | x | x | x | x | x | x |
| WV(DG)-<br>SFN631 | x | x | x | x | x | x |
| WV(DG)-<br>SFV110 | x | x | x | x | x | x |
| WV(DG)-<br>SFV130 | x | x | x | x | x | x |
| WV(DG)-<br>SFV311 | x | x | x | x | x | x |
| WV(DG)-<br>SFV531 | x | x | x | x | x | x |
| WV(DG)-<br>SFV611 | x | x | x | x | x | x |
| WV(DG)-<br>SFV631 | x | x | x | x | x | x |
| WV(DG)-<br>SP102  | x | x | x | x | x | x |
| WV(DG)-<br>SP105  | x | x | x | x | x | x |
| WV(DG)-<br>SP304  | x | x | x | x | x | x |
| WV(DG)-<br>SP305  | x | x | x | x | x | x |
| WV(DG)-<br>SP509  | x | x | x | x | x | x |
| WV(DG)-<br>SPN310 | x | x | x | x | x | x |
| WV(DG)-<br>SPN311 | x | x | x | x | x | x |
| WV(DG)-<br>SPN531 | x | x | x | x | x | x |
| WV(DG)-<br>SPN611 | x | x | x | x | x | x |

|                   |   |   |   |   |   |   |
|-------------------|---|---|---|---|---|---|
| WV(DG)-<br>SPN631 | × | × | × | × | × | × |
| WV(DG)-<br>SPW310 | × | × | × | × | × | × |
| WV(DG)-<br>SPW311 | × | × | × | × | × | × |
| WV(DG)-<br>SPW611 | × | × | × | × | × | × |
| WV(DG)-<br>SPW631 | × | × | × | × | × | × |
| WV(DG)-<br>SUD638 | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SW155  | × | × | × | × | × | × |
| WV(DG)-<br>SW158  | × | × | × | × | × | × |
| WV(DG)-<br>SW314  | × | × | × | × | × | × |
| WV(DG)-<br>SW316  | × | × | × | × | × | × |
| WV(DG)-<br>SW355  | × | × | × | × | × | × |
| WV(DG)-<br>SW395  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SW396  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SW397  | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>SW458  | △ | △ | △ | △ | △ | △ |
| WV(DG)-<br>SW559  | × | × | × | × | × | × |
| WV(DG)-<br>SW598  | ○ | ○ | ○ | ○ | ○ | ○ |

|                  |   |   |   |   |   |   |
|------------------|---|---|---|---|---|---|
| WV(DG)-<br>X6511 | ○ | ○ | ○ | ○ | ○ | ○ |
| WV(DG)-<br>X6531 | ○ | ○ | ○ | ○ | ○ | ○ |

○：動作します △：動作保証外です ×：動作しません

## ●AXIS

|         | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|---------|--------|-----|-------|--------------|--------------|-------|
| M1004-W | ×      | ×   | ×     | ×            | ×            | ×     |
| M1011   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1025   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1034-W | ×      | ×   | ×     | ×            | ×            | ×     |
| M1045   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1054   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1065   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1103   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1104   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1113   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1114   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1124   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1125   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1144   | ×      | ×   | ×     | ×            | ×            | ×     |
| M1145   | ×      | ×   | ×     | ×            | ×            | ×     |
| M2014-E | ×      | ×   | ×     | ×            | ×            | ×     |
| M2025   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3006   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3011   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3014   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3024   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3025   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3044   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3045   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3104   | ×      | ×   | ×     | ×            | ×            | ×     |
| M3105   | ×      | ×   | ×     | ×            | ×            | ×     |

|       |   |   |   |   |   |   |
|-------|---|---|---|---|---|---|
| M3113 | × | × | × | × | × | × |
| M3114 | × | × | × | × | × | × |
| M3203 | × | × | × | × | × | × |
| M3204 | × | × | × | × | × | × |
| M5013 | ○ | ○ | × | × | ○ | ○ |
| M5014 | ○ | ○ | × | × | ○ | ○ |
| M5054 | ○ | ○ | ○ | ○ | ○ | ○ |
| M5065 | ○ | ○ | ○ | ○ | ○ | ○ |
| M5525 | ○ | ○ | ○ | ○ | ○ | ○ |
| M7001 | △ | △ | △ | △ | △ | △ |
| M7011 | △ | △ | △ | △ | △ | △ |
| P1204 | × | × | × | × | × | × |
| P1214 | × | × | × | × | × | × |
| P1311 | × | × | × | × | × | × |
| P1343 | × | × | × | × | × | × |
| P1344 | × | × | × | × | × | × |
| P1346 | × | × | × | × | × | × |
| P1353 | × | × | × | × | × | × |
| P1354 | × | × | × | × | × | × |
| P1355 | × | × | × | × | × | × |
| P1364 | × | × | × | × | × | × |
| P1365 | × | × | × | × | × | × |
| P1405 | × | × | × | × | × | × |
| P1425 | × | × | × | × | × | × |
| P3214 | × | × | × | × | × | × |
| P3215 | × | × | × | × | × | × |
| P3225 | × | × | × | × | × | × |
| P3235 | × | × | × | × | × | × |
| P3301 | × | × | × | × | × | × |
| P3304 | × | × | × | × | × | × |
| P3343 | × | × | × | × | × | × |
| P3344 | × | × | × | × | × | × |
| P3346 | × | × | × | × | × | × |
| P3353 | × | × | × | × | × | × |
| P3354 | × | × | × | × | × | × |



|       |   |   |   |   |   |   |
|-------|---|---|---|---|---|---|
| P3363 | × | × | × | × | × | × |
| P3364 | × | × | × | × | × | × |
| P3365 | × | × | × | × | × | × |
| P3374 | × | × | × | × | × | × |
| P3375 | × | × | × | × | × | × |
| P3384 | × | × | × | × | × | × |
| P5414 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5415 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5512 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5514 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5515 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5522 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5532 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5534 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5624 | ○ | ○ | ○ | ○ | ○ | ○ |
| P5635 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q1602 | × | × | × | × | × | × |
| Q1604 | × | × | × | × | × | × |
| Q1614 | × | × | × | × | × | × |
| Q1615 | × | × | × | × | × | × |
| Q1635 | × | × | × | × | × | × |
| Q1645 | × | × | × | × | × | × |
| Q1755 | × | ○ | ○ | ○ | × | × |
| Q1765 | × | × | × | × | × | × |
| Q1775 | × | ○ | ○ | ○ | ○ | ○ |
| Q1941 | × | × | × | × | × | × |
| Q3505 | × | × | × | × | × | × |
| Q3515 | × | × | × | × | × | × |
| Q3615 | × | × | × | × | × | × |
| Q6042 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q6044 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q6054 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q6055 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q6115 | ○ | ○ | ○ | ○ | ○ | ○ |
| Q7401 | △ | △ | △ | △ | △ | △ |

|       |   |   |   |   |   |   |
|-------|---|---|---|---|---|---|
| Q7404 | △ | △ | △ | △ | △ | △ |
| Q7411 | △ | △ | △ | △ | △ | △ |
| Q8414 | × | × | × | × | × | × |
| V5915 | ○ | ○ | ○ | ○ | ○ | ○ |

○：動作します △：動作保証外です ×：動作しません

## ●SONY

|                | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|----------------|--------|-----|-------|--------------|--------------|-------|
| SNC-CH110      | ×      | ×   | ×     | ×            | ×            | ×     |
| SNC-CH120      | ×      | ×   | ○     | ○            | ×            | ×     |
| SNC-CH140      | ×      | ×   | ○     | ○            | ×            | ×     |
| SNC-CH160      | ×      | ○   | ○     | ○            | ×            | ×     |
| SNC-CH180      | ×      | ○   | ○     | ○            | ×            | ×     |
| SNC-CH210      | ×      | ×   | ×     | ×            | ×            | ×     |
| SNC-CH220      | ×      | ×   | ○     | ○            | ×            | ×     |
| SNC-CH240      | ×      | ×   | ○     | ○            | ×            | ×     |
| SNC-CH260      | ×      | ○   | ×     | ×            | ×            | ×     |
| SNC-CH280      | ×      | ○   | ×     | ×            | ×            | ×     |
| SNC-CX600      | ×      | ×   | ×     | ×            | ×            | ×     |
| SNC-<br>CX600W | ×      | ×   | ×     | ×            | ×            | ×     |
| SNC-DH110      | ×      | ×   | ×     | ×            | ×            | ×     |
| SNC-DH120      | ×      | ○   | ○     | ○            | ×            | ×     |
| SNC-DH140      | ×      | ○   | ○     | ○            | ×            | ×     |

|            |   |   |   |   |   |   |
|------------|---|---|---|---|---|---|
| SNC-DH160  | × | ○ | ○ | ○ | × | × |
| SNC-DH180  | × | ○ | ○ | ○ | × | × |
| SNC-DH210  | × | × | × | × | × | × |
| SNC-DH220  | × | ○ | ○ | ○ | × | × |
| SNC-DH240  | × | ○ | ○ | ○ | × | × |
| SNC-DH260  | × | ○ | ○ | ○ | × | × |
| SNC-DH280  | × | ○ | ○ | ○ | × | × |
| SNC-EB600  | × | × | ○ | ○ | × | × |
| SNC-EB600B | × | × | × | × | × | × |
| SNC-EB602R | × | ○ | ○ | ○ | × | × |
| SNC-EB630  | × | × | ○ | ○ | × | × |
| SNC-EB630B | × | × | × | × | × | × |
| SNC-EB632R | × | ○ | ○ | ○ | × | × |
| SNC-EB640  | × | × | ○ | ○ | × | × |
| SNC-EB642  | × | ○ | ○ | ○ | × | × |
| SNC-EM600  | × | ○ | ○ | ○ | × | × |
| SNC-EM602R | × | ○ | ○ | ○ | × | × |
| SNC-EM630  | × | ○ | ○ | ○ | × | × |
| SNC-EM632R | × | ○ | ○ | ○ | × | × |

|            |   |   |   |   |   |   |
|------------|---|---|---|---|---|---|
| SNC-EM641  | × | ○ | ○ | ○ | × | × |
| SNC-RS86N  | ○ | × | × | × | △ | △ |
| SNC-VB600  | × | × | ○ | ○ | × | × |
| SNC-VB600B | × | × | ○ | ○ | × | × |
| SNC-VB630  | × | × | ○ | ○ | × | × |
| SNC-VB632  | × | ○ | ○ | ○ | × | × |
| SNC-VB635  | × | × | ○ | ○ | × | × |
| SNC-VB640  | × | × | ○ | ○ | × | × |
| SNC-VB642  | × | ○ | ○ | ○ | × | × |
| SNC-VM600B | × | ○ | ○ | ○ | × | × |
| SNC-VM600  | × | ○ | ○ | ○ | × | × |
| SNC-VM602R | × | ○ | ○ | ○ | × | × |
| SNC-VM630  | × | ○ | ○ | ○ | × | × |
| SNC-VM632R | × | ○ | ○ | ○ | × | × |
| SNC-VM642  | × | ○ | ○ | ○ | × | × |
| SNC-WR600  | ○ | × | × | × | ○ | ○ |
| SNC-WR602  | ○ | × | × | × | △ | △ |
| SNC-WR630  | ○ | × | × | × | ○ | ○ |
| SNC-WR632  | ○ | × | × | × | △ | △ |

|                |   |   |   |   |   |   |
|----------------|---|---|---|---|---|---|
| SNC-<br>XM631  | × | × | × | × | × | × |
| SNC-<br>XM632  | × | × | × | × | × | × |
| SNC-ZB550      | × | × | ○ | ○ | × | × |
| SNC-<br>ZM550  | × | ○ | ○ | ○ | × | × |
| SNT-<br>EX101E | △ | △ | △ | △ | △ | △ |
| SNT-EX104      | △ | △ | △ | △ | △ | △ |

○：動作します △：動作保証外です ×：動作しません

## ● CANON

|         | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|---------|--------|-----|-------|--------------|--------------|-------|
| VB-C500 | ×      | ×   | ×     | ×            | ×            | ×     |
| VB-C60  | ○      | ○   | ×     | ○            | ×            | ×     |
| VB-H41  | ○      | ○   | ×     | ○            | ×            | ×     |
| VB-H43  | ○      | ○   | ×     | ○            | ×            | ×     |
| VB-H45  | ○      | ○   | ×     | ○            | ×            | ×     |
| VB-H610 | ×      | ×   | ×     | ○            | ×            | ×     |
| VB-H630 | ×      | ×   | ×     | ○            | ×            | ×     |
| VB-H651 | ×      | ×   | ×     | ○            | ×            | ×     |
| VB-H652 | ×      | ×   | ×     | ○            | ×            | ×     |

|         |   |   |   |   |   |   |
|---------|---|---|---|---|---|---|
| VB-H710 | × | × | × | ○ | × | × |
| VB-H730 | × | × | × | ○ | × | × |
| VB-H751 | × | × | × | ○ | × | × |
| VB-H760 | × | ○ | × | ○ | × | × |
| VB-H761 | × | ○ | × | ○ | × | × |
| VB-M40  | ○ | ○ | × | ○ | × | × |
| VB-M42  | ○ | ○ | × | ○ | × | × |
| VB-M44  | ○ | ○ | × | ○ | × | × |
| VB-M50  | ○ | ○ | × | ○ | × | × |
| VB-M600 | × | × | × | ○ | × | × |
| VB-M620 | × | × | × | ○ | × | × |
| VB-M640 | × | × | × | ○ | × | × |
| VB-M641 | × | × | × | ○ | × | × |
| VB-M700 | × | × | × | ○ | × | × |
| VB-M720 | × | × | × | ○ | × | × |
| VB-M740 | × | × | × | ○ | × | × |
| VB-M741 | × | × | × | ○ | × | × |

|         |   |   |   |   |   |   |
|---------|---|---|---|---|---|---|
| VB-R10  | ○ | ○ | × | ○ | × | × |
| VB-R11  | ○ | ○ | × | ○ | × | × |
| VB-R12  | ○ | ○ | × | ○ | × | × |
| VB-R13  | ○ | ○ | × | ○ | × | × |
| VB-S30  | ○ | ○ | × | ○ | × | × |
| VB-S31  | ○ | ○ | × | × | × | × |
| VB-S800 | × | × | × | × | × | × |
| VB-S805 | × | × | × | × | × | × |
| VB-S900 | × | × | × | × | × | × |
| VB-S905 | × | × | × | × | × | × |
| VB-S910 | × | ○ | × | ○ | × | × |

○：動作します △：動作保証外です ×：動作しません

## ● ELMO

|                 | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|-----------------|--------|-----|-------|--------------|--------------|-------|
| ESN-H2300       | ×      | ×   | ×     | ×            | ×            | ×     |
| ESN-H2500       | ×      | ×   | ×     | ×            | ×            | ×     |
| ESN-<br>H2500VP | ×      | ×   | ×     | ×            | ×            | ×     |
| ESN-<br>H8500WP | ×      | ×   | ×     | ×            | ×            | ×     |

|           |   |   |   |   |   |   |
|-----------|---|---|---|---|---|---|
| ESN-H9300 | × | × | × | × | × | × |
| ESN-H9500 | × | × | × | × | × | × |

○：動作します △：動作保証外です ×：動作しません

## ●JVC ケンウッド

|         | パン・チルト | ズーム    | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|---------|--------|--------|-------|--------------|--------------|-------|
| VN-H128 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H137 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H157 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H168 | ×      | ○      | ×     | ×            | ×            | ×     |
| VN-H228 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H237 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H257 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H268 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H28  | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H37  | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H328 | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H57  | ×      | ×      | ×     | ×            | ×            | ×     |
| VN-H678 | ○ (※1) | ○ (※2) | ×     | ×            | ○            | ○     |



○：動作します △：動作保証外です ×：動作しません

※1：上下反転（卓上設置）時、パン・チルトの上下左右が逆に動作します。

※2：ズームの移動範囲が非常に大きいですが、カメラの仕様であり本機の異常ではありません。

## ●TOA

|         | パン・チルト | ズーム | フォーカス | オート<br>フォーカス | ホーム<br>ポジション | プリセット |
|---------|--------|-----|-------|--------------|--------------|-------|
| N-C3100 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3120 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3200 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3220 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3300 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3420 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C3500 | ○      | ○   | ○     | ○            | ○            | ○     |
| N-C3700 | ○      | ○   | ○     | ○            | ○            | ○     |
| N-C3820 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C5120 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C5150 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C5220 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C5250 | ×      | ×   | ×     | ×            | ×            | ×     |
| N-C5420 | ×      | ×   | ×     | ×            | ×            | ×     |

|         |   |   |   |   |   |   |
|---------|---|---|---|---|---|---|
| N-C5450 | × | × | × | × | × | × |
| N-C5820 | × | × | × | × | × | × |
| N-C5850 | × | × | × | × | × | × |

○：動作します △：動作保証外です ×：動作しません